



# **LG290P (03)&LGx80P (03)**

## **Firmware Upgrade Guide**

**GNSS Module Series**

Version: 1.1

Date: 2025-07-22

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

**Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local offices. For more information, please visit:**

<http://www.quectel.com/support/sales.htm>.

**For technical support, or to report documentation errors, please visit:**

<http://www.quectel.com/support/technical.htm>.

Or email us at: [support@quectel.com](mailto:support@quectel.com).

## Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an "as available" basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

## Use and Disclosure Restrictions

### License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

### Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

## Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

## Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

## Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

## Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

**Copyright © Quectel Wireless Solutions Co., Ltd. 2025. All rights reserved.**

# About the Document

## Document Information

Title	LG290P (03)&LGx80P (03) Firmware Upgrade Guide
Subtitle	GNSS Module Series
Document Type	Firmware Upgrade Guide
Document Status	Released

## Revision History

Version	Date	Description
-	2024-05-23	Creation of the document
1.0	2024-07-15	First official release
1.1	2025-07-22	<ul style="list-style-type: none"><li>1. Added applicable modules LG580P (03) and LG680P (03).</li><li>2. Updated the time of waiting for entire firmware to be fully upgraded (<a href="#">Figure 4</a>).</li><li>3. Updated the firmware upgrade example (<a href="#">Chapter 3</a>).</li><li>4. Updated the version of QGNSS tool and related contents (<a href="#">Chapter 4</a>).</li></ul>

## Contents

About the Document .....	3
Contents .....	4
Table Index .....	5
Figure Index .....	6
<b>1 Introduction .....</b>	<b>7</b>
<b>2 Firmware Upgrade Process .....</b>	<b>8</b>
2.1. Connect Module .....	8
2.2. Synchronize Module .....	9
2.3. Firmware Upgrade Protocol .....	10
2.4. Upgrade Procedure (ClassID = 0x02) .....	12
2.4.1. Send Firmware Information.....	13
2.4.1.1. Host Message (MsgID = 0x02) .....	13
2.4.1.2. Module Response (MsgID = 0x00) .....	13
2.4.2. Send Erase Firmware Command.....	13
2.4.2.1. Host Message (MsgID = 0x03) .....	13
2.4.2.2. Module Response (MsgID = 0x00) .....	14
2.4.3. Send Firmware .....	14
2.4.3.1. Host Message (MsgID = 0x04) .....	14
2.4.3.2. Module Response (MsgID = 0x00) .....	14
2.4.4. Send Reset Command.....	15
2.4.4.1. Host Message (MsgID = 0x31) .....	15
2.4.4.2. Module Response (MsgID = 0x00) .....	15
2.4.5. Query Bootloader Version.....	15
2.4.5.1. Host Send (MsgID = 0x71).....	15
2.4.5.2. Module Response (MsgID = 0x00) .....	16
<b>3 Firmware Upgrade Example .....</b>	<b>17</b>
<b>4 Upgrade Example by QGNSS .....</b>	<b>19</b>
<b>5 Appendix A References.....</b>	<b>25</b>
<b>6 Appendix B CRC32 Calculation.....</b>	<b>26</b>

## Table Index

Table 1: Constant List.....	8
Table 2: Field Description.....	10
Table 3: Messages Overview .....	11
Table 4: Response Status .....	11
Table 5: Firmware Information.....	13
Table 6: Related Document.....	25
Table 7: Terms and Abbreviations .....	25

## Figure Index

Figure 1: Firmware Upgrade Connection.....	7
Figure 2: Synchronization Sequence .....	9
Figure 3: Structure of Upgrade Protocol .....	10
Figure 4: Firmware Upgrade Procedure .....	12
Figure 5: EVB Connection.....	19
Figure 6: Device Manager.....	20
Figure 7: Device Information .....	21
Figure 8: Firmware Download .....	21
Figure 9: Load Firmware .....	22
Figure 10: Firmware Selection .....	22
Figure 11: Wait for Synchronization .....	23
Figure 12:Wait for Upgrading to Complete .....	23
Figure 13: Firmware Upgrade Completed.....	24

# 1 Introduction

This document explains the firmware upgrading process on Quectel LG290P (03), LG580P (03) and LG680P (03) GNSS module.

Once the module is connected to the host via UART, the firmware upgrade process can be initiated.




Figure 1: Firmware Upgrade Connection

**NOTE**

If the process fails or is manually stopped, no backup firmware can be executed. The only solution is to reset the module and initiate a new upgrade process to reprogram a functional firmware.

## 2 Firmware Upgrade Process

This chapter explains all the relevant steps in the firmware upgrade process. All constants in this document are defined in the following table.

**Table 1: Constant List**

Constant Name	Constant Value
SYNC_WORD1	0x514C1309
RSP_WORD1	0xAAFC3A4D
SYNC_WORD2	0x1203A504
RSP_WORD2	0x55FD5BA0

### 2.1. Connect Module

Connect the module to the host via UART to decode NMEA messages. For LG290P (03), LG580P (03), and LG680P (03), UART1, UART2 and UART3 support firmware upgrade.

The parameters of UART interface should be configured as follows:

- Baud rate: 460800 bps
- Data bit: 8
- Stop bit: 1
- Parity bit: None
- Flow control: None

## 2.2. Synchronize Module

Synchronization steps between host and module.




Figure 2: Synchronization Sequence

**Step 1:** Host continuously sends the **SYNC\_WORD1** to the module at 20 ms intervals. If the module receives **SYNC\_WORD1** within 500 ms from power up, the module will respond with **RSP\_WORD1** and go to Step 2. Otherwise, the module exits firmware upgrade mode and continues to run the firmware already stored in Flash.

**Step 2:** Host sends **SYNC\_WORD2** to the module once. When the module receives **SYNC\_WORD2**, it will respond with **RSP\_WORD2** to indicate that the host successfully synchronized with module and the module entered command mode. Otherwise, the module exits firmware upgrade mode and continues to run the firmware already stored in Flash.

**NOTE**

The **SYNC\_WORD** and **RSP\_WORD** are transmitted in little-endian format.

## 2.3. Firmware Upgrade Protocol




Figure 3: Structure of Upgrade Protocol

Table 2: Field Description

Field	Description
<b>Header</b>	Frame header, fixed at 0xAA.
<b>ClassID</b>	Class ID indicates the group that the message belongs to, see <a href="#">Table 3: Messages Overview</a> for more details.
<b>MsgID</b>	Message ID indicates the specific message identifier, see <a href="#">Table 3: Messages Overview</a> for more details.
<b>Payload Length</b>	2-byte payload content in <b>big-endian</b> format.
<b>Payload</b>	Message content. Maximum length: 5 KB.
<b>CRC32</b>	CRC32 checksum in <b>big-endian</b> format.
<b>Tail</b>	Frame tail, fixed at 0x55.

**Table 3: Messages Overview**

<b>ClassID</b>	<b>MsgID</b>	<b>Description</b>
0x02	0x00	Module responds to the message whose ClassID is 0x02.
	0x02	Host sends the firmware information.
	0x03	Host sends the command to erase the firmware.
	0x04	Host sends the firmware package.
	0x31	Host sends the command to reset module.
	0x71	Host queries the bootloader version.

**Table 4: Response Status**

<b>Status (2 Bytes)</b>	<b>Description</b>
0x0000	Message received and executed successfully.
0x0001	Unknown error.
0x0002	CRC32 checksum error.
0x0003	Timeout.
0x0004	Unsupported message.
0x0005	Message package error.
0x0020	Firmware area erase error.
0x0021	Firmware write to Flash error.

**NOTE**

**ClassID** and **MsgID** contained in the **Payload** of the module response in this document are the same as **ClassID** and **MsgID** of the command sent by the host. The **Payload** of the module response contains **ClassID** (Class ID), **MsgID** (message ID) and **Response Status**.

## 2.4. Upgrade Procedure (ClassID = 0x02)

This chapter outlines the module firmware upgrade procedure and related messages.




Figure 4: Firmware Upgrade Procedure

## 2.4.1. Send Firmware Information

### 2.4.1.1. Host Message (MsgID = 0x02)

Header	ClassID	MsgID	Payload Length	Payload	CRC32	Tail
0xAA	0x02	0x02	0x0010	See <a href="#">Table 5: Firmware Information</a>	4 Bytes	0x55

Table 5: Firmware Information

Name	Byte	Description
FW Size	4	Firmware size (unit: byte, big-endian).
FW CRC32	4	Checksum (big-endian), which contains the firmware size in little-endian format and the entire firmware.
DestAddr	4	Start address of firmware. Fixed at 0x00000000 (big-endian).
Reversed	4	Reserved parameters. Set to 0x00000000.

### 2.4.1.2. Module Response (MsgID = 0x00)

Header	ClassID	MsgID	Payload Length	Payload			CRC32	Tail
				ClassID	MsgID	Response Status		
0xAA	0x02	0x00	0x0004	0x02	0x02	See <a href="#">Table 4: Response Status</a>	4 Bytes	0x55

## 2.4.2. Send Erase Firmware Command

### 2.4.2.1. Host Message (MsgID = 0x03)

Header	ClassID	MsgID	Payload Length	Payload	CRC32	Tail
0xAA	0x02	0x03	0x0000	-	4 Bytes	0x55

### 2.4.2.2. Module Response (MsgID = 0x00)

Header	ClassID	MsgID	Payload Length	Payload				
				ClassID	MsgID	Response Status	CRC32	Tail
0xAA	0x02	0x00	0x0004	0x02	0x03	See <a href="#">Table 4: Response Status</a>	4 Bytes	0x55

### 2.4.3. Send Firmware

#### 2.4.3.1. Host Message (MsgID = 0x04)

Header	ClassID	MsgID	Payload Length	Payload				
				Packet Sequence <sup>1)</sup>	Firmware Content <sup>2)</sup>	CRC32	Tail	
0xAA	0x02	0x04	2 Bytes	4 Bytes	4 KB per packet except the last packet	4 Bytes	0x55	

**NOTE**

1. <sup>1)</sup> **Packet Sequence** starts from 0x00000000 (big-endian).
2. <sup>2)</sup> **Firmware Content** contains several data packets. The size of each packet is 4 KB except the last packet which contains the remaining firmware data (size: ≤ 4 KB).

#### 2.4.3.2. Module Response (MsgID = 0x00)

Header	ClassID	MsgID	Payload Length	Payload				
				ClassID	MsgID	Response Status	CRC32	Tail
0xAA	0x02	0x00	0x0004	0x02	0x04	See <a href="#">Table 4: Response Status</a>	4 Bytes	0x55

## 2.4.4. Send Reset Command

### 2.4.4.1. Host Message (MsgID = 0x31)

Header	ClassID	MsgID	Payload Length	Payload		CRC32	Tail
0xAA	0x02	0x31	0x0000	-		4 Bytes	0x55

### 2.4.4.2. Module Response (MsgID = 0x00)

Header	ClassID	MsgID	Payload Length	Payload		Response Status	CRC32	Tail
				ClassID	MsgID			
0xAA	0x02	0x00	0x0004	0x02	0x31	See <a href="#">Table 4: Response Status</a>	4 Bytes	0x55

## 2.4.5. Query Bootloader Version

This chapter explains how to query bootloader version. Ensure that the module has entered the command mode before query.

### 2.4.5.1. Host Send (MsgID = 0x71)

Header	ClassID	MsgID	Payload Length	Payload	CRC32	Tail
0xAA	0x02	0x71	0x0000	-	4 Bytes	0x55

#### 2.4.5.2. Module Response (MsgID = 0x00)

Header	ClassID	MsgID	Payload Length	Payload					
				ClassID	MsgID	Response Status	Major	Minor	Build
0xAA	0x02	0x00	0x0007	0x02	0x71	See <a href="#">Table 4: Response Status</a>	1 Byte	1 Byte	1 Byte
CRC	Tail								
4 Bytes	0x55								

# 3 Firmware Upgrade Example

This chapter takes LG290P (03) as an example to provide the example of firmware upgrade procedure.

```
//Host is continuously sending SYNC_WORD1 at 20 ms intervals.  
09 13 4C 51  
09 13 4C 51  
09 13 4C 51  
...  
09 13 4C 51  
09 13 4C 51  
09 13 4C 51  
09 13 4C 51  
//Module responds with RSP_WORD1.  
4D 3A FC AA  
//Host sends SYNC_WORD2.  
04 A5 03 12  
//Module responds with RSP_WORD2.  
A0 5B FD 55  
//Host sends firmware information.  
AA 02 02 00 10 00 26 5D B4 A5 D1 82 54 00 00 00 00 00 00 00 00 18 50 BC BC 55  
//Module responds.  
AA 02 00 00 04 02 02 00 00 7B 0A 62 31 55  
//Host sends command for erasing firmware.  
AA 02 03 00 00 89 0B A9 CE 55  
//Module responds.  
AA 02 00 00 04 02 03 00 00 7A C8 08 06 55  
//Host sends firmware binary data packet 1  
AA 02 04 10 04 00 00 00 00 70 00 00 00 00 00 10 00 03 00 ...  
//Module responds.  
AA 02 00 00 04 02 04 00 00 7F 87 1E 83 55  
//Host sends firmware binary data packet 2  
AA 02 04 10 04 00 00 00 01 58 14 10 00 58 14 10 00 D8 13 ...  
//Module responds.  
AA 02 00 00 04 02 04 00 00 7F 87 1E 83 55  
...  
//Host sends firmware the last binary packet n.  
AA 02 04 0D B8 00 00 02 65 00 00 00 00 00 00 00 00 00 00 00 00 ...
```

//Module responds.

**AA 02 00 00 04 02 04 00 00 7F 87 1E 83 55**

//Host sends reset command.

**AA 02 31 00 00 AE E4 98 30 55**

//Module responds.

**AA 02 00 00 04 02 31 00 00 5D 27 39 F8 55**

//Module restarts.

# 4 Upgrade Example by QGNSS

This chapter provides a step-by-step guide to upgrade module firmware via QGNSS tool. Quectel GNSS MODULE EVB (V1.3) and the LG290P (03) module are used as an example in this chapter. For details about the EVB, see [document \[1\] EVB user guide](#).

Connect the EVB to your PC through the GNSS-USB interface as shown below:




Figure 5: EVB Connection

## Notes:

1. Before initiating the firmware upgrade, ensure that the module is connected to the PC and powered on normally as shown below:




Figure 6: Device Manager

2. Ensure QGNSS V2.0 or a later version is used.

**Firmware upgrade steps are as follows:**

**Step 1:** Open QGNSS tool and click to access the “Device Information” window as shown in [Figure 7: Device Information.](#)

**Step 2:** Choose the module to be upgraded.

**Step 3:** Choose port number.

**Step 4:** Choose baudrate. Default baudrate: 460800.

**Step 5:** Click “OK”.




Figure 7: Device Information

Step 6: Click “Tools” as shown in [Figure 8: Firmware Download](#).

Step 7: Choose “Firmware Download” in the drop-down menu of “Tools”.




Figure 8: Firmware Download

Step 8: Click  to choose the firmware upgrade package whose name is identifiable by the presence of “pkg” before the extension name as shown in [Figure 10: Firmware Selection](#).

**Step 9:** Click  to start the firmware upgrade process and wait for synchronization between the module and the PC as shown in [Figure 11: Wait for Synchronization](#). Manually reset the module within 90 s; otherwise, the firmware upgrade will fail. In this case, you can retry from **Step 9**:




Figure 9: Load Firmware

Name	Date modified	Type	Size
LG290P03AANR01A03S.pkg	30/04/2024 18:10	PKG File	2,452 KB

Figure 10: Firmware Selection




Figure 11: Wait for Synchronization

**Step 10:** Wait for upgrading to complete.





Figure 12:Wait for Upgrading to Complete

**Step 11:** Firmware upgrade is successful. After the upgrade is complete, the module will automatically restart.



**Figure 13: Firmware Upgrade Completed**

# 5 Appendix A References

**Table 6: Related Document**

Document Name
[1] Quectel_GNSS-MODULE_EVB_User_Guide

**Table 7: Terms and Abbreviations**

Abbreviation	Description
CRC32	Cyclic Redundancy Check 32
FW	Firmware
GNSS	Global Navigation Satellite System
RSP	Response
SYNC	Synchronization
UART	Universal Asynchronous Receiver/Transmitter

# 6 Appendix B CRC32 Calculation

Sample code for calculating CRC32.

```
const uint32_t Table_CRC32[256] =
{
    0x00000000, 0x77073096, 0xee0e612c, 0x990951ba, 0x076dc419,
    0x706af48f, 0xe963a535, 0x9e6495a3, 0x0edb8832, 0x79dcb8a4,
    0xe0d5e91e, 0x97d2d988, 0x09b64c2b, 0x7eb17cbd, 0xe7b82d07,
    0x90bf1d91, 0x1db71064, 0x6ab020f2, 0xf3b97148, 0x84be41de,
    0x1adad47d, 0x6ddde4eb, 0xf4d4b551, 0x83d385c7, 0x136c9856,
    0x646ba8c0, 0xfd62f97a, 0x8a65c9ec, 0x14015c4f, 0x63066cd9,
    0xfa0f3d63, 0x8d080df5, 0x3b6e20c8, 0x4c69105e, 0xd56041e4,
    0xa2677172, 0x3c03e4d1, 0x4b04d447, 0xd20d85fd, 0xa50ab56b,
    0x35b5a8fa, 0x42b2986c, 0xdbbbc9d6, 0xacbcf940, 0x32d86ce3,
    0x45df5c75, 0xdcd60dcf, 0abd13d59, 0x26d930ac, 0x51de003a,
    0xc8d75180, 0xbfd06116, 0x21b4f4b5, 0x56b3c423, 0xcfba9599,
    0xb8bda50f, 0x2802b89e, 0x5f058808, 0xc60cd9b2, 0xb10be924,
    0x2f6f7c87, 0x58684c11, 0xc1611dab, 0xb6662d3d, 0x76dc4190,
    0x01db7106, 0x98d220bc, 0efd5102a, 0x71b18589, 0x6b6b51f,
    0x9fbfe4a5, 0xe8b8d433, 0x7807c9a2, 0xf00f934, 0x9609a88e,
    0xe10e9818, 0x7f6a0ddb, 0x086d3d2d, 0x91646c97, 0x6635c01,
    0x6b6b51f4, 0x1c6c6162, 0x856530d8, 0xf262004e, 0x6c0695ed,
    0x1b01a57b, 0x8208f4c1, 0xf50fc457, 0x65b0d9c6, 0x12b7e950,
    0x8bbeb8ea, 0xfc9887c, 0x62dd1ddf, 0x15da2d49, 0x8cd37cf3,
    0xfb44c65, 0x4db26158, 0x3ab551ce, 0xa3bc0074, 0xd4bb30e2,
    0x4adfa541, 0x3dd895d7, 0xa4d1c46d, 0xd3d6f4fb, 0x4369e96a,
    0x346ed9fc, 0xad678846, 0xda60b8d0, 0x44042d73, 0x33031de5,
    0xaa0a4c5f, 0xdd0d7cc9, 0x5005713c, 0x270241aa, 0xbe0b1010,
    0xc90c2086, 0x5768b525, 0x206f85b3, 0xb966d409, 0xce61e49f,
    0x5edef90e, 0x29d9c998, 0xb0d09822, 0xc7d7a8b4, 0x59b33d17,
    0x2eb40d81, 0xb7bd5c3b, 0xc0ba6cad, 0xedb88320, 0x9abfb3b6,
    0x03b6e20c, 0x74b1d29a, 0xeade54739, 0x9dd277af, 0x04db2615,
    0x73dc1683, 0xe3630b12, 0x94643b84, 0xd6d6a3e, 0x7a6a5aa8,
    0xe40ecf0b, 0x9309ff9d, 0xa00ae27, 0x7d079eb1, 0xf00f9344,
    0x8708a3d2, 0x1e01f268, 0x6906c2fe, 0xf762575d, 0x806567cb,
    0x196c3671, 0x6e6b06e7, 0xfed41b76, 0x89d32be0, 0x10da7a5a,
    0x67dd4acc, 0xf9b9df6f, 0x8ebeeff9, 0x17b7be43, 0x60b08ed5,
    0xd6d6a3e8, 0xa1d1937e, 0x38d8c2c4, 0x4fdff252, 0xd1bb67f1,
    0xa6bc5767, 0x3fb506dd, 0x48b2364b, 0xd80d2bda, 0xaf0a1b4c,
```

```
0x36034af6, 0x41047a60, 0xdf60efc3, 0xa867df55, 0x316e8eef,
0x4669be79, 0xcb61b38c, 0xbc66831a, 0x256fd2a0, 0x5268e236,
0xcc0c7795, 0xbb0b4703, 0x220216b9, 0x5505262f, 0xc5ba3bbe,
0xb2bd0b28, 0x2bb45a92, 0x5cb36a04, 0xc2d7ffa7, 0xb5d0cf31,
0x2cd99e8b, 0xbdeae1d, 0x9b64c2b0, 0xec63f226, 0x756aa39c,
0x026d930a, 0x9c0906a9, 0xeb0e363f, 0x72076785, 0x05005713,
0x95bf4a82, 0xe2b87a14, 0x7bb12bae, 0xcb61b38, 0x92d28e9b,
0xe5d5be0d, 0x7cdcef7, 0xbdbdf21, 0x86d3d2d4, 0xf1d4e242,
0x68ddb3f8, 0x1fda836e, 0x81be16cd, 0xf6b9265b, 0x6fb077e1,
0x18b74777, 0x88085ae6, 0xff0f6a70, 0x66063bca, 0x11010b5c,
0x8f659eff, 0xf862ae69, 0x616bffd3, 0x166ccf45, 0xa00ae278,
0xd70dd2ee, 0x4e048354, 0x3903b3c2, 0xa7672661, 0xd06016f7,
0x4969474d, 0x3e6e77db, 0xaed16a4a, 0xd9d65adc, 0x40df0b66,
0x37d83bf0, 0xa9bcae53, 0xdebb9ec5, 0x47b2cf7f, 0x30b5ffe9,
0xbdbdf21c, 0xcabac28a, 0x53b39330, 0x24b4a3a6, 0xbad03605,
0xcdd70693, 0x54de5729, 0x23d967bf, 0xb3667a2e, 0xc4614ab8,
0x5d681b02, 0x2a6f2b94, 0xb40bbe37, 0xc30c8ea1, 0x5a05df1b,
0x2d02ef8d
};

uint32_t Q1_CRC32(const unsigned char *pData, const uint32_t Length)
{
    uint32_t i = 0;
    uint32_t CRC_Result = 0xFFFFFFFF;

    if((NULL == pData) || (Length == 0))
    {
        return 0;
    }

    for (i = 0; i < Length; i++)
    {
        CRC_Result = Table_CRC32[(CRC_Result ^ pData[i]) & 0xFF] ^ (CRC_Result >> 8);
    }

    return (CRC_Result ^ 0xFFFFFFFF);
}
```